

# INSTALLATION INSTRUCTIONS

Rear Wheel Well Inner Liner

Ram 2009+

LIK-62



## List of Contents:

1 Pc. Passenger's side Inner Wheel Well Liner



1 Pc. Installation Kit

20 pc. Plastic Push lock pin



1 Pc. Driver's side Inner Wheel Well Liner



1 pc. Installation Instructions.

## Preparations:

Clean the interior panels of the rear Wheel house.

Installation time estimated: 20 min.

## Instructions:

**PLEASE READ INSTRUCTIONS CAREFULLY BEFORE STARTING THE INSTALLATION.**

**NOTE:** One person can do the installation.

**1.** Starting on Passenger side locate the holes on the sheet metal, making sure no screws or push pins are present



**2.** Mount the Inner Wheel Well Liner marked as (PS) inside the inner panel of the wheel house.



**3.** Insert the bottom sides behind the metal flange .



**4.** Insert the upper section of the plastic liner behind the metal flange, make sure all around edges are inside the metal wheel well house edge.



## Care and Maintenance Recommendations

To protect the appearance of this product, wash with soap and water

# INSTALLATION INSTRUCTIONS

Rear Wheel Well Inner Liner

Ram 2009+

LIK-62



**7.** Locate the 2 pre-drilled holes on the front of the plastic Wheel Well and Install one plastic push lock pin on each.



**8.** Locate pre-drilled holes on the body of the Inner Wheel Well Liner, align holes with pre-drilled holes located at the wheel house flange, then install one push lock pin in each hole.



## To install Driver's side Inner Wheel Well Repeat steps 1 - 8

### For trucks WITH factory Mod Flaps

- A.** Remove mod flaps before Inner Well Well Installation
- B.** Follow steps 1-8 to install Inner Wheel Well liner
- C.** Re-install the Mod Flap



#### Care and Maintenance Recommendations

To protect the appearance of this product, wash with soap and water